

# INSTRUCTIONS FOR RE-TUNING YOUR HEALING HSS851 RECEIVER TO THE OPTUS D2 SATELLITE

Please follow the steps as listed and do not change anything unless specified and please do not reset your receiver to factory setting if you are unable to complete the re-tune.

Warning – Attempt the re-tuning of your set top box at your own risk. Christian Satellite is not liable for any damage or loss of programming that may be incurred by following these instructions.

**PLEASE BE AWARE – THESE INSTRUCTIONS WILL BE INEFFECTIVE IF YOU HAVE PERFORMED A FACTORY RESET**

## STEP 1 - Deleting the current channel list

- A. Turn on your TV and receiver
- B. By using your remote press the **MENU** button and highlight **CHANNEL ORGANIZER** and press the **OK** button. The receiver may request a password. Enter **9402** and press **OK** twice or if that does not work try **0000** and press **OK** button twice.
- C. Next highlight **CHANNEL MANAGER** and press the **OK** button
- D. Next press the **BLUE (RCL)** button on your remote and the receiver will display a message “**DELETE ALL CHANNELS IN CURRENT SATELLITE?**” highlight **OK** and press the **OK** button
- E. Next press the **EXIT** button

## STEP 2 – Scanning the new frequency for the Christian Channels

- A. Next press the **EXIT** button and highlight **INSTALLATION** and press **OK**. The receiver will request a password. Enter **9402** press **OK** twice or if that does not work try **0000** and press the **OK** button twice
- B. Next highlight **AUTO SCAN** and press the **OK** button
- C. Next scroll through the **SATELLITE NAME** list on the left and highlight **OPTUS B3**
- D. Next press the **GREEN (TEXT)** button on the remote to change the **SCAN MODE** to **FREE** on the right window
- E. Next press the **YELLOW (SUB)** button on the remote to change **BLIND SCAN** to **ON**
- F. Next **please check all of the setting before continuing**
- G. Next press the **RED (SAT)** button on the remote and the receiver will start scanning the satellite for all the new channels.
- H. The scan may take 3 to 5 min's. When the receiver is finished scanning it will exit out of the installation menu

Please note that the receiver will scan all the channels on that Frequency so the Christian Channels will not be grouped and will be mixed between the other foreign channels.

If you wish to delete any of the foreign channels, Please follow **STEP 3**

## STEP 3 - Deleting unwanted Channels

- A. When the scan is finished. Press the **MENU** button and highlight **CHANNEL ORGANIZER** and press the **OK** button. The receiver may request a password. Enter **9402** and press **OK** twice or if that does not work try **0000** and press **OK** twice
- B. Next highlight **CHANNEL MANAGER** and press the **OK** button
- C. Next press **UP** or **DOWN** and highlight the channel that you would like to delete
- D. Next press **LEFT** or **RIGHT** and highlight the **DEL COLUMN** on the right and press the **OK** button. The unwanted channels should have an **X** in the **DEL COLUMN**. Continue this with the various channels until you have **X** mark in front of all the channels that you want to delete.
- E. When you are finish press the **EXIT** button on the remote and the receiver will display a message “**DELETE SELECT CHANNELS**” highlight **OK** and press the **OK** button

If you would like to group your favorite's channels together in the Channel list please follow **STEP 4**

## **STEP 4 - Grouping your favourite channels together in the channel list**

- A.** Highlight **CHANNEL ORGANIZER** and press the **OK** button
- B.** Next press **UP** or **DOWN** and highlight the channel that you would like to move.
- C.** Next scroll **LEFT** or **RIGHT** and highlight the **MOVE COLUMN** and press the **OK** button
- D.** Next move the channel to where you would like it to appear in the list and press the **OK** button. Continue this with the various channels until you are satisfied with the list.
- E.** Once you are finished press the **EXIT** button on the remote and the receiver will save the setting
- F.** When the receiver is finished press the **EXIT** button twice to exit the installation menu.

Please make sure all of the channels are working and are in your order of preference.

The Christian Channels:

- 1. Hope Channel**
- 2. 3ABN**
- 3. Trinity**
- 4. JCTV**
- 5. The Church Channel**
- 6. Smile of a Child**
- 7. God TV**
- 8. Daystar TV**
- 9. Inspiration Network**
- 10. EWTN**
- 11. Apostolic Oneness Network (AON)**

Other Channels of Interest

- 1. Press TV**
- 2. Russia Today**