

# INSTRUCTIONS FOR RE-TUNING YOUR SOUTHERN CROSS DVBS-2888 RECEIVER TO THE OPTUS D2 SATELLITE

Please follow the steps as listed and do not change anything unless specified and please do not reset your receiver to factory setting if you are unable to complete the re-tune.

Warning – Attempt the re-tuning of your set top box at your own risk. Christian Satellite is not liable for any damage or loss of programming that may be incurred by following these instructions.

PLEASE BE AWARE – THESE INSTRUCTIONS WILL BE INEFFECTIVE IF YOU HAVE PERFORMED A FACTORY RESET

## STEP 1 - Deleting the current channel list

1. Turn on your TV and receiver
2. By using your remote press the **MENU** button and scroll left by using the **V+/V-** button and highlight **CHANNEL**
3. Next scroll down by using **CH+/CH-** button and highlight **DELETE ALL** and press the **OK** button. The receiver may request a password. Enter **0000**. If **0000** is not working you will need to contact your installer for the password
4. Next a **“Warning”** window will appear. Select **YES** and press the **OK** button

## STEP 2 - Re-scanning the new frequency for the Christian Channels

1. From the **MAIN MENU** scroll left or right and highlight **INSTALLATION**
2. Next scroll down and highlight **TP SCAN** and press the **OK** button. The receiver may request a password. Enter **0000**. If **0000** is not working you will need to contact your installer for the password
3. Next scroll down and highlight **SATELLITE** and press the **OK** button
4. Next scroll up or down in the list of satellite and highlight **OPTUS B3 152E** and press the **OK** button
5. Next scroll down and highlight **TP INDEX** and scroll left or right and select **1/19**
6. Next scroll down and highlight **TP FREQUENCY** and by using the number keys on the remote enter **12706**
7. Next scroll down and highlight **SYMBOL RATE** and by using the number keys on the remote enter **22500**
8. Next scroll down and highlight **POLARITY** and by using **V+/V-** key on the remote select **V**
9. Next scroll down and highlight **SCAN MODE** and by using **V+/V-** key on the remote select **FREE**
10. Next scroll down and highlight **SEARCH** and press the **OK** button and the receiver will start scanning
11. Next press the **EXIT** button to exit the **TP SCAN** window
12. When the scan is finished you will need to scan 3 more frequencies to get all the Christian channels
13. Next scroll up and highlight **TP INDEX** and scroll left or right and select **2/19**
14. Next scroll down and highlight **TP FREQUENCY** and by using the number keys on the remote enter **12644**
15. Next scroll down and highlight **SYMBOL RATE** and by using the number keys on the remote. Enter **22500**
16. Next scroll down and highlight **POLARITY** and by using **V+/V-** key on the remote. Select **V**
17. Next scroll down and highlight **SCAN MODE** and by using **V+/V-** key on the remote. Select **FREE**
18. Next scroll down and highlight **SEARCH** and press the **OK** button and the receiver will start scanning
19. Next press the **EXIT** button to exit the **TP SCAN** window
20. When the scan is finished you will need to scan 2 more frequencies to get all the Christian channels
21. Next scroll up and highlight **TP INDEX** and scroll left or right and select **3/19**
22. Next scroll down and highlight **TP FREQUENCY** and by using the number keys on the remote enter **12518**
23. Next scroll down and highlight **SYMBOL RATE** and by using the number keys on the remote enter **22500**
24. Next scroll down and highlight **POLARITY** and by using **V+/V-** key on the remote select **V**
25. Next scroll down and highlight **SCAN MODE** and by using **V+/V-** key on the remote select **FREE**
26. Next scroll down and highlight **SEARCH** and press the **OK** button and the receiver will start scanning
27. Next press the **EXIT** button to exit the **TP SCAN** window
28. When the scan is finished you will need to scan 1 more frequency to get all the Christian channels
29. Next scroll up and highlight **TP INDEX** and scroll left or right and select **4/19**
30. Next scroll down and highlight **TP FREQUENCY** and by using the number keys on the remote enter **12734**
31. Next scroll down and highlight **SYMBOL RATE** and by using the number keys on the remote enter **22500**
32. Next scroll down and highlight **POLARITY** and by using **V+/V-** key on the remote select **V**
33. Next scroll down and highlight **SCAN MODE** and by using **V+/V-** key on the remote select **FREE**
34. Next scroll down and highlight **SEARCH** and press the **OK** button and the receiver will start scanning
35. When the scan is finished press the **EXIT** button to exit the **TP SCAN** window
36. Next press the **EXIT** button to exit the **TP SCAN** menu

Once you have finished **STEP 2** please follow **STEP 3**.

Please note that the receiver will scan all the channels on that Frequency so the Christian Channels will not be grouped and will be mixed between the other foreign channels.

If you wish to delete any of the foreign channels, Please follow **STEP 3**.

### **STEP 3 - Deleting unwanted Channels**

- A.** From the **MAIN MENU** scroll left by using the **V+/V-** button and highlight **CHANNEL**
- B.** Next scroll down and highlight **TV CHANNEL LIST** and press the **OK** button. The receiver may request a password. Enter **0000**
- C.** Next press the number **5** key to enter **EDIT MODE**. The receiver may request a password. Enter **0000**
- D.** Next scroll through the channel list and press the number **1** key on all the unwanted channels in the list and all the unwanted channels should have an **X** next to them.
- E.** When you are finished checking the channels that you have selected press the **EXIT** button on the remote and the receiver will display a message "**Warning!**" Highlight **YES** and press the **OK** button and the receiver will exit out of the TV channel list menu.

If you would like to group your favorite's channels together in the Channel list please follow **STEP 4**.

### **STEP 4 - Grouping your favourite channels together in the channel list**

- A.** From the **MAIN MENU** scroll left by using the **V+/V-** button and highlight **CHANNEL**
- B.** Next scroll down and highlight **TV CHANNEL LIST** and press the **OK** button. The receiver may request a password. Enter **0000**
- C.** Next scroll through the channel list and press the number **2** key button on the channel that you would like to move. Now scroll **UP** or **DOWN** and move the channel to where you would like it to appear in the list and press **OK**. Continue this with the various channels until you are satisfied with the list.
- D.** Once you are finished press the **EXIT** button on the remote until you are out of the main menu.

Please make sure all of the channels are working and are in your order of preference.

The Christian Channels:

- 1. Hope Channel**
- 2. 3ABN**
- 3. Trinity**
- 4. JCTV**
- 5. The Church Channel**
- 6. Smile of a Child**
- 7. God TV**
- 8. Daystar TV**
- 9. Inspiration Network**
- 10. EWTN**
- 11. Apostolic Oneness Network (AON)**

Other Channels of Interest

- 1. Press TV**
- 2. Russia Today**