

# INSTRUCTIONS FOR RE-TUNING YOUR STRONG SRT 3500 RECEIVER TO THE OPTUS D2 SATELLITE

Please follow the steps as listed and do not change anything unless specified and please do not reset your receiver to factory setting if you are unable to complete the re-tune.

Warning – Attempt the re-tuning of your set top box at your own risk. Christian Satellite is not liable for any damage or loss of programming that may be incurred by following these instructions.

PLEASE BE AWARE – THESE INSTRUCTIONS WILL BE INEFFECTIVE IF YOU HAVE PERFORMED A FACTORY RESET

## STEP 1 - Deleting the current channel list

- A. Turn on your TV and receiver
- B. By using your remote press the **MENU** button and then scroll **LEFT** or **RIGHT** by using the **VOL- VOL+** button and highlight **SETUP** and press the **OK** button.
- C. Next scroll **DOWN** by using the **CHANNEL** buttons and highlight **ADVANCED** and press the **OK** button.
- D. Next scroll **DOWN** and highlight **ERASE CHANNELS** and press the **OK** button. The receiver may request a password. Enter **9402** or **0000** and a “**WARNING ARE YOU SURE**” window will appear highlight **YES** and press the **OK** button.
- E. Next a **WELCOME** window will appear press the **EXIT** button and go to **STEP 2**

## STEP 2 - Adding new frequency for the Christian Channels

- A. Press the **MENU** button and scroll **LEFT** or **RIGHT** by using the **VOL- VOL+** button and highlight **SETUP** and press the **OK** button.
- B. Next highlight **SATELLITE** and press the **OK** button.
- C. Next highlight **SCAN TRANSPONDER** and press the **OK** button. The receiver may request a password. Enter **9402** by using the numbers on the remote and if that does not work try **0000**.
- D. Next highlight **SATELLITE** and press the **OK** button and a window will pop up.
- E. Next in the list scroll **UP** or **DOWN** and highlight **OPTUS B3 152.0 E** press the **OK** button.
- F. Next scroll **DOWN** and highlight **FREQ (MHz)** and slowly enter **12706** by using the numbers on the remote.
- G. Next scroll **DOWN** and highlight **SR (KsPS)** and slowly enter **22500** by using the numbers on the remote.
- H. Next scroll **DOWN** and highlight **LNB SELECT** and press the **VOL –** or **VOL +** button and select **LNB 4**.
- I. Next scroll **DOWN** and highlight **LNB POLARISATION** and press the **VOL –** or **VOL +** button and select **V**.
- J. Next scroll **DOWN** and highlight **SCAN TYPE** and press the **VOL –** or **VOL +** button and select **FTA**.
- K. Next scroll **DOWN** and highlight **TV / RADIO** and select **DATA**
- L. Next scroll **DOWN** and highlight **OK TO START SCAN** please note before you press the **OK** button please check that the **SIGNAL QUALITY** bar at the bottom of the screen is more than **0%** and then press the **OK** button and the receiver will begin searching for the channels. If the **SIGNAL QUALITY** bar at the bottom of the screen is not more than **0%** you may be using an **AUSTRA** or **FOXTEL** dish so you will need to change the **LNB SELECT** in **STEP 1** to **LNB 3** and then press the **OK** button.
- M. When the receiver is finished scanning a “**TUNING**” **NO SERVICE(S) ADDED** window will appear. Press the **OK** button and the receiver will exit to the main menu.
- N. Next scroll **UP** and highlight **SATELLITE SCAN** and press the **OK** button. The receiver may request a password. Enter **9402** by using the numbers on the remote and if that does not work try **0000**.
- O. Next highlight **SATELLITE** and press the **OK** button and a window will pop up.
- P. Next in the list scroll **UP** or **DOWN** and highlight **OPTUS B3 152.0 E** press the **OK** button.
- Q. Next scroll **DOWN** and highlight **XPDR SELECT** and press **LEFT** or **RIGHT** and select **12706 / 22500 /V**.
- R. Next scroll **DOWN** and highlight **SEARCH TYPE** and press **LEFT** or **RIGHT** and select **TP NETWORK SEARCH**.
- S. Next scroll to **OK TO START SCAN** and press the **OK** button.
- T. When the receiver is finished scanning a “**TUNING**” window will appear. Press the **OK** button and the receiver will exit to the main menu.

Please note that the receiver will scan all the channels on that Frequency so the Christian Channels will not be grouped and will be mixed between the other foreign channels.

If you wish to delete any of the foreign channels, Please follow **STEP 3**

### STEP 3 - Deleting unwanted Channels

- A. From the **MAIN MENU**, press the **VOL-** button and scroll **DOWN** and highlight **CHANNELS** and press the **OK** button.
- B. Next scroll **DOWN** and highlight **SERVICE SETUP** and press the **OK** button. The receiver may request a password enter **9402** by using the numbers on the remote and if that does not work try **0000**
- C. Now by pressing the **CHANNEL** buttons scroll through the channel list and highlight the unwanted channels
- D. Next press the **RED** button on the remote and an **X** will appear on the right of the channel. Continue step **C** and **D** with all the unwanted channels.
- E. Once you are finished press the **OK** button on the remote and the receiver will delete all of the unwanted channels.

If you would like to move your favorite channels together in the Channel list please follow **STEP 4**. If not press the **EXIT** button **3** times and the receiver will exit out of the main menu. You have finished!!

### STEP 4 - Grouping your favourite channels together in the channel list

- A. To move your favorite channels press the **CHANNEL** buttons and highlight the channel that you would like to move and then press the **GREEN** button on the remote and the channel will highlight in green
- B. Next scroll **UP** or **DOWN** and highlight where you would like the channel to appear in the list and then press the **GREEN** button. Continue with step **A** and **B** with all the channels that you would like to move.
- C. Once you are finished press the **EXIT** button on the remote and the receiver will save the changes and exit to the main menu.
- D. Next press the **EXIT** button **3** times and the receiver will exit out of the main menu. You have finished!!

Please make sure all of the channels are working and are in your order of preference.

The Christian Channels:

1. **Hope Channel**
2. **3ABN**
3. **Trinity**
4. **JCTV**
5. **The Church Channel**
6. **Smile of a Child**
7. **God TV**
8. **Daystar TV**
9. **Inspiration Network**
10. **EWTN**
11. **Apostolic Oneness Network (AON)**

Other Channels of Interest

1. **Press TV**
2. **Russia Today**